




1. General information

Thank you for purchasing this high-quality product. Please read these operating instructions carefully before using the appliance for the first time and keep them for future reference.

If you have any technical questions, you can contact us at any time by e-mail at service@telestar.de.

2. Safety instructions

Please read these safety instructions carefully before using the appliance. Observe all warnings and instructions on the appliance and in this user manual.

- Not a toy. Keep out of reach of children.
- Never direct the arc towards people or animals. Keep away from the face, skin, hair and clothing.
- Do not touch the electrodes or the arc whilst

the device is in operation.

- Keep away from highly flammable materials, liquids, gases and vapours.
- Do not open, dismantle or modify the device. Repairs must only be carried out by qualified personnel.
- Protect from impacts, crushing and sharp or pointed objects.
- Do not submerge the device. Use and charge only when dry. Keep the USB-C port dry.
- Only remove residue from the electrodes when the device is switched off and has cooled down, using a dry, soft brush or a non-metallic tool.
- For charging, use only a suitable USB port or a USB power supply with 5 V DC / max. 3000 mA.
- Do not use the device whilst it is charging. Remove the charging cable once the device is fully charged.
- Do not expose to direct sunlight, open flames or temperatures above 50 °C.
- Do not continue to use the device if it is damaged, or if it becomes unusually hot, emits an odour or produces smoke.
- Do not use the arc as a light source. Use only the LED torch for this purpose.
- After use, ensure that the arc is switched off and close the safety flap.

3. Operation

The TELESTAR CL 12 is equipped with a rechargeable Li-Ion battery (3.7 V, 220 mAh). The integrated booster technology converts the low battery voltage into a semi-sine wave high voltage (7 kV at 15 kHz) and generates an arc with an extremely high temperature between the electrodes.

Thanks to this technology, the lighter is ideal for lighting cigarettes, candles, fireplaces and other highly flammable materials. Thanks to its rechargeability, it is an environmentally friendly alternative to conventional gas or petrol lighters.

Charging the battery:

Charge the device fully before using it for the first time. To do this, use the USB port of a laptop or a suitable mobile device charger (max. 5 V DC, 3000 mA).

1. Connect the USB-C socket of the lighter to the USB port or charger - use the cable supplied.
2. The charging process takes about 2-3 hours.
3. The charge level indicator goes out as soon as the charging process is complete.
4. Disconnect the charger when fully charged - the lighter is now ready for use.

Ignition:

1. Open the safety flap by turning the handle and pressing the silver locking button.
2. Then press the ignition button to create an arc.
3. Hold the object to be ignited against the arc.

The ignition process ends when you release the button or automatically after approx. 6-8 seconds thanks to the integrated overload protection.

After an automatic switch-off, the appliance must cool down briefly before it can be used again.

Torch:

The LED torch can also be activated by pressing the ignition button. The safety flap must be closed when doing so.

4. Specifications

- USB ARC lighter (arc lighter)
- Torch function with two operating modes (normal light and SOS flashing light)
- Integrated compass
- Protection class: IP56 (dust- and water-jet-proof)
- Material: Zinc alloy / ABS
- Robust paint finish (Baking Paint)
- Battery capacity: 220 mAh
- Operating time:
 - Torch approx. 2.5 hours
 - Arc: approx. 50 ignitions
- Nominal voltage: 3.7 volts
- Charging connection: USB-C (DC 5 V, max. 3 A)
- Charging time: approx. 2 hours
- Dimensions: 31 x 108 x 22 mm (W/H/D)
- Weight: 43 g

Conformity information

Telestar GmbH hereby declares that the following device is in compliance with the essential requirements and other relevant provisions of the RoHS Directive 2011/65/EU including Delegated Directive (EU) 2015/863 and the REACH

Regulation (EC) No. 1907/2006:

TELESTAR CL 12 (item no. 5100005)

The declaration of conformity for these products is available from the company TELESTAR GmbH, Brückenstraße 2a, D-97618 Niederlauer

You can download the declaration of conformity from our homepage:

<https://www.telestar.de/support/dl/>

Disposal instructions



This electrical appliance must not be disposed of with household waste. Please hand in the old appliance free of charge at a local collection point or a designated retail take-back point.

The battery is permanently fitted inside the appliance. Do not attempt to remove the battery yourself or open the appliance. Please hand in the appliance in its entirety at the collection point. The battery will be properly removed and recycled as part of the processing of the old appliance.

TELESTAR GmbH
Brückenstraße 2a
D-97618 Niederlauer

www.telestar.de
info@telestar.de



Version 1.1
(08/2026)